

**TM 00539-13/1**

**U. S. MARINE CORPS TECHNICAL MANUAL**

---

**OPERATION AND MAINTENANCE**

**RIFLE, SNIPER, M40A1  
AND  
RELATED OPTICAL EQUIPMENT**

**NSN 1005-01-035-1674**



---

**NOVEMBER 1981**

**PCN 184 004900 00**

DEPARTMENT OF THE NAVY  
Headquarters, U.S. Marine Corps  
Washington, D.C. 20380

30 November 1981

1. This Manual is effective upon receipt and provides instructions for the operation and maintenance of the M40A1 Sniper Rifle and related optical equipment, the Unertl Sniper Scope.
2. Notice of discrepancies and suggested changes should be forwarded on NAVMC 10772 to the Commandant of the Marine Corps (LMA-1).

BY DIRECTION OF THE COMMANDANT OF THE MARINE CORPS

OFFICIAL:



L. CHAKER  
Head, Materiel Acquisition Support Branch  
Materiel Division  
Installations and Logistics Department

DISTRIBUTION: AA/BN

Copy to: 7000161(3)

1/(2 blank)

## TABLE OF CONTENTS

### CHAPTER 1. INTRODUCTION AND GENERAL INFORMATION

<u>Par</u>		<u>Page</u>
1-1.	Description and Related Data.....	1-1
1-3.	Authorized Forms.....	1-2
1-3a.	NAVMC 1018.....	1-2
1-3b.	NAVMC 11003.....	1-2
1-3c.	NAVMC 10558A.....	1-2
1-4.	Issue and Recovery of Individual Rifles.....	1-3

### CHAPTER 2. OPERATION

#### Section I. M40A1 Sniper Rifle..... 2-1

<u>Par</u>		
2-1.	Introduction.....	2-1
2-2.	Inspection Upon Receipt.....	2-1
2-3.	Operating Controls.....	2-1
2-3a.	Safety.....	2-1
2-3b.	Magazine Release.....	2-1
2-3c.	Bolt Handle.....	2-3
2-3d.	Trigger.....	2-3
2-4.	Loading and Unloading the Rifle.....	2-3

#### Section II. The Unertl Sniper Scope..... 2-6

<u>Par</u>		
2-5.	Introduction.....	2-6
2-6.	Related Tabulated Data.....	2-6
2-7.	Adjustments.....	2-6
2-7a.	Scope Focus.....	2-6
2-7b.	Focusing the Eyepiece.....	2-10
2-7c.	Parallax.....	2-10
2-7d.	Eye Relief.....	2-12
2-7e.	Reticle.....	2-12
2-8.	Zeroing.....	2-12
2-8c.	Zeroing the Scope.....	2-12
2-9.	Field Expedient Zeroing.....	2-14
2-9a.	900-Inch Method.....	2-14
2-9b.	Unknown-Distance Zeroing.....	2-18

### CHAPTER 3. OPERATIONAL AND ORGANIZATIONAL MAINTENANCE

#### Section I. The M40A1 Rifle..... 3-1

<u>Par</u>		
3-1.	Introduction.....	3-1

TABLE OF CONTENTS (Continued)

CHAPTER 3. OPERATIONAL AND ORGANIZATIONAL MAINTENANCE

Par

3-2.	Allocation of Maintenance Tasks.....	3-1
3-3.	M40A1 Rifle Maintenance.....	3-2
3-3a.	Inspection.....	3-2
3-3b.	Cleaning.....	3-2
3-3c.	Repair.....	3-7
3-4.	Care of Optical Equipment.....	3-8
3-4a.	Cleaning the Scope Lens.....	3-8
3-4b.	Operation in Cold Climate.....	3-8
3-4c.	Operation in Hot, Humid Climate and Salt Water Atmosphere.....	3-11
3-4d.	Handling Telescope.....	3-11
3-4e.	Field Maintenance.....	3-11

CHAPTER 4. AMMUNITION

4-1.	General.....	4-1
4-2.	Care and Handling.....	4-1