


**ARMY TM 9-1005-201-23&P**  
**\*MARINE CORPS TM 08671A-23&P/2A**  
**AIR FORCE TO 11W3-5-5-52**  
Supersedes copy dated 1 April 1984

**TECHNICAL MANUAL**  
**UNIT AND DIRECT SUPPORT MAINTENANCE MANUAL**  
**(INCLUDING REPAIR PARTS AND SPECIAL TOOLS LIST)**  
**FOR**

**MACHINE GUN, 5.56MM, M249 w/EQUIP**  
**(NSN 1005-01-127-7510) (EIC: 4BG)**



**WARNING** - This document contains export-controlled technical data whose export is restricted by the Arms Export Control Act (Title 22, U.S.C., Sec 2751 et seq) or Executive Order 12470. Violation of these export laws are subject to severe criminal penalties.

**DISTRIBUTION STATEMENT C.** Distribution authorized to U.S. Government agencies and their contractors. This publication is required for administration and operational purposes, as determined 31 October 1990. Other requests for this document shall be referred to Commander, U.S. Army Armament, Munitions and Chemical Command, ATTN: AMSMC-MAS, Rock Island, IL 61299-6000.

**DESTRUCTION NOTICE** - For unclassified, limited documents, destroy by any method that will prevent disclosure of contents or reconstruction of the document.

**HEADQUARTERS, DEPARTMENT OF THE ARMY,**  
**U.S. MARINE CORPS AND AIR FORCE**

**TECHNICAL MANUAL  
ARMY NO. 9-1005-201-23&P  
MARINE CORPS NO. 08671A-23&P/2A  
TECHNICAL ORDER  
AIR FORCE NO. 11W3-5-5-52**

**DEPARTMENTS OF ARMY,  
MARINE CORPS AND AIR FORCE  
Washington, D.C., 14 December 1990**

**UNIT AND DIRECT SUPPORT  
MAINTENANCE MANUAL  
(Including Repair Parts and Special Tools List)  
for  
MACHINE GUN, 5.56MM, M249  
(1005-01-127-7510)**

**REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS**

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms) or DA Form 2028-2 located in the back of this manual direct to: Commander, U.S. Army Armament, Munitions and Chemical Command, ATTN: AMSMC-MAS, Rock Island, IL 61299-6000. A reply will be furnished to you.

Marine Corps users submit NAVMC Form 10772 to: Commander, Marine Corps Logistics Base (Code 850), Albany, GA 31704-5000. Marine Corps units should also submit a copy to MARCORSSYSCOM, ATTN: (CBG) Quantico, VA 22134-5080, of the NAVMC Form 10772 or via Naval message.

Air Force users submit AFTO Form 22, Technical Order System Publications Improvement Report, and reply to: WR-ALC/LZDTA, Robins AFB, GA 31098-5330.

**WARNING** - This document contains export-controlled technical data whose export is restricted by the Arms Export Control Act (Title 22, U.S.C., Sec 2751 et seq) or Executive Order 12470. Violation of these export laws are subject to severe criminal penalties.

**DISTRIBUTION STATEMENT C.** Distribution authorized to U.S. Government agencies and their contractors. This publication is required for administration and operational purposes, as determined 31 October 1990. Other requests for this document shall be referred to Commander, U.S. Army Armament, Munitions and Chemical Command, ATTN: AMSMC-MAS, Rock Island, IL 61299-6000.

**DESTRUCTION NOTICE** - For unclassified, limited documents, destroy by any method that will prevent disclosure of contents or reconstruction of the document.

**\*This manual supersedes Army TM 9-1005-201-23&P and Marine Corps TM 08671A-23&P/2, 1 April 1984, including all changes.**

**Change 3**

TABLE OF CONTENTS

		Page
<b>CHAPTER</b>	<b>1. INTRODUCTION</b>	
	Chapter Overview .....	1-1
Section	I. General Information .....	1-1
Section	II. Equipment Description and Data .....	1-2
<b>CHAPTER</b>	<b>2. UNIT MAINTENANCE INSTRUCTIONS</b>	
	Chapter Overview .....	2-1
Section	I. Repair Parts, Special Tools, and Common Tools and Equip- ment .....	2-1
Section	II. Service Upon Receipt .....	2-1
Section	III. Preventive Maintenance Checks and Services (PMCS) .....	2-3
Section	IV. Troubleshooting .....	2-10
Section	V. Maintenance Procedures .....	2-18.8
	Machine Gun .....	2-19
	Return Rod and Transfer Mechanism Assembly or Rod Assembly, Operating and Drive Spring .....	2-21
	Bolt Assembly .....	2-22.1
	Slide Assembly .....	2-26
	Piston Assembly .....	2-28
	Heat Shield .....	2-29
	Barrel Assembly, Gas Collar, and Gas Regulator .....	2-30
	Handguard Assembly .....	2-37
	Buttstock/Buffer or Buttstock and Shoulder Assembly .....	2-38.2
	Trigger Mechanism Assembly .....	2-40
	Gas Cylinder .....	2-42
	Blpod Assembly .....	2-43
	Receiver Assembly .....	2-44
	Sling and Snap Hook Assembly .....	2-48
Section	VI. Installation and Maintenance of Adapter Assembly for M122 Tripod Mount .....	2-49
	Installation of Adapter Assembly .....	2-49
	Maintenance of Adapter Assembly .....	2-50
Section	VII. Utilization of Auxiliary Equipment .....	2-52
	Application of Rack, Storage, Small Arms, M13 .....	2-52
<b>CHAPTER</b>	<b>3. DIRECT SUPPORT MAINTENANCE INSTRUCTIONS</b>	
	Chapter Overview .....	3-1
Section	I. Repair Parts, Special Tools, Common Tools and Equipment and Fabricated Tools .....	3-1
Section	II. Troubleshooting .....	3-1

**TABLE OF CONTENTS (CONT)**

		<b>Page</b>
<b>CHAPTER</b>	<b>3. DIRECT SUPPORT MAINTENANCE INSTRUCTIONS (Cont)</b>	
<b>Section</b>	<b>III. Maintenance Procedures</b> .....	<b>3-1</b>
	Machine Gun .....	3-2
	Bolt Assembly .....	3-4
	Slide Assembly .....	3-5
	Piston Assembly .....	3-7
	Barrel Assembly .....	3-9
	Buttstock and Shoulder Assembly or Buttstock/Buffer Assembly ..	3-16.1
	Trigger Mechanism Assembly .....	3-18
	Bipod Assembly .....	3-21
	Cover and Feed Mechanism Assembly .....	3-26
	Feed Tray .....	3-26
	Cover Removal .....	3-27
	Feed Lever .....	3-28
	Cartridge Retainer Pawls .....	3-28
	Feed Pawl Assembly .....	3-29
	Cover Latches .....	3-29
	Rear Sight Assembly .....	3-30
	Receiver Assembly .....	3-44
	Gas Cylinder Retaining Spring .....	3-44
	Ejection Port Cover .....	3-45
	Cocking Handle .....	3-46
	Magazine Cover .....	3-47
	Barrel Locking Lever .....	3-47
	Receiver .....	3-48
<b>Section</b>	<b>IV. Final Inspection</b> .....	<b>3-52</b>
	Headspace Check .....	3-52
	Firing Pin Protrusion Check .....	3-54
	Trigger Pull Test .....	3-55
	Functional Test of Machine Gun .....	3-56
<b>Section</b>	<b>V. Preparation for Storage or Shipment</b> .....	<b>3-56</b>
	Cleaning, Preserving, Packaging, Packing and Marking .....	3-56
<b>Section</b>	<b>VI. Preembarkation Inspection of Material</b> .....	<b>3-58</b>
<b>APPENDIX</b>	<b>A. REFERENCES</b> .....	<b>A-1</b>
<b>APPENDIX</b>	<b>B. MAINTENANCE ALLOCATION CHART</b> .....	<b>B-1</b>
<b>Section</b>	<b>I. Introduction</b> .....	<b>B-1</b>
<b>Section</b>	<b>II. Maintenance Allocation Chart</b> .....	<b>B-4</b>
<b>Section</b>	<b>III. Tool and Test Equipment Requirements for Machine Gun</b> .....	<b>B-8</b>
<b>Section</b>	<b>IV. Remarks</b> .....	<b>B-9</b>